

GEARBOX & TRANSFER COMBINATION KITS – 2021.

MAKE	MODEL	YEAR	ENGINE	PART NO.	NOTES
TOYOTA					
LANDCRUISER	BJ40	4/1975-7/1980	B Diesel	GBK2/TK3	4 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	BJ40	8/1980-10/1984	B Diesel	GBK2/TK4	4 Speed
LANDCRUISER	BJ42	8/1980-10/1984	3B Diesel	GBK2/TK4	4 Speed
LANDCRUISER	BJ42	10/1982-10/1984	3B Diesel	GBK3/TK4	5 Speed
LANDCRUISER	BJ43	4/1975-7/1980	B Diesel	GBK2/TK3	4 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	BJ45	8/1980-11/1985	3B Diesel	GBK2/TK4	4 Speed
LANDCRUISER	BJ60	8/1980-10/1982	3B Diesel	GBK2/TK4	4 Speed
LANDCRUISER	BJ60	10/1982-10/1985	3B Diesel	GBK3/TK4	5 Speed
LANDCRUISER	BJ70	11/1984-10/1985	3B Diesel	GBK3/TK4	5 Speed
LANDCRUISER	BJ73	11/1984-10/1985	3B Diesel	GBK3/TK4	5 Speed
LANDCRUISER	BJ75	11/1984-9/1985	3B Diesel	GBK3/TK4	5 Speed
LANDCRUISER	BJ75	10/1985-12/1989	3B Diesel	GBK4/TK5	5 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	FJ40	4/1975-7/1980	2F Petrol	GBK2/TK3	4 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	FJ40	8/1980-10/1984	F Petrol	GBK2/TK4	4 Speed
LANDCRUISER	FJ40	10/1982-10/1984	2F Petrol	GBK3/TK4	5 Speed
LANDCRUISER	FJ45	4/1975-7/1980	2F Petrol	GBK2/TK3	4 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	FJ45	8/1980-10/1984	F Petrol	GBK2/TK4	4 Speed
LANDCRUISER	FJ45	10/1982-10/1984	2F Petrol	GBK3/TK4	5 Speed
LANDCRUISER	FJ55	4/1975-7/1980	2F Petrol	GBK2/TK3	4 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	FJ60	8/1980-10/1982	2F Petrol	GBK2/TK4	4 Speed
LANDCRUISER	FJ60	10/1982-10/1985	2F Petrol	GBK3/TK4	5 Speed
LANDCRUISER	FJ60	10/1985-	2F Petrol	GBK4/TK5	5 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	FJ62	10/1982-10/1985	3F Petrol	GBK3/TK4	5 Speed
LANDCRUISER	FJ62	10/1985-	3F Petrol	GBK4/TK5	5 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	FJ70	11/1984-10/1985	3F Petrol	GBK3/TK4	5 Speed
LANDCRUISER	FJ70	10/1985-	3F Petrol	GBK4/TK5	5 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	FJ73	11/1984-10/1985	3F Petrol	GBK3/TK4	5 Speed
LANDCRUISER	FJ73	10/1985-	3F Petrol	GBK4/TK5	5 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	FJ75	11/1984-10/1985	3F Petrol	GBK3/TK4	5 Speed
LANDCRUISER	FJ75	10/1985-	3F Petrol	GBK4/TK5	5 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	HJ45	4/1975-7/1980	H Diesel	GBK2/TK3	4 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	HJ45	8/1980-10/1984	H Diesel	GBK2/TK4	4 Speed
LANDCRUISER	HJ47	8/1980-10/1984	H Diesel	GBK2/TK4	4 Speed
LANDCRUISER	HJ47	10/1982-10/1984	2H Diesel	GBK3/TK4	5 Speed
LANDCRUISER	HJ60	8/1980-10/1982	2H Diesel	GBK2/TK4	4 Speed
LANDCRUISER	HJ60	10/1982-10/1985	2H Diesel	GBK3/TK4	5 Speed
LANDCRUISER	HJ60	10/1985-	2H Diesel	GBK4/TK5	5 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	HJ61	10/1982-10/1985	12HT Diesel	GBK3/TK4	5 Speed
LANDCRUISER	HJ61	10/1985-	12HT Diesel	GBK4/TK5	5 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	HJ62	10/1985-	12HT Diesel	GBK4/TK5	5 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	HJ75	11/1984-10/1985	2H Diesel	GBK3/TK4	5 Speed
LANDCRUISER	HJ75	10/1985-	2H Diesel	GBK4/TK5	5 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	HZJ70	1/1990-	1HZ Diesel	GBK4/TK5	5 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	HZJ73	1/1990-	1HZ Diesel	GBK4/TK5	5 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	HZJ75	1/1990-	1HZ Diesel	GBK4/TK5	5 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	HZJ78	8/1999-	1HZ Diesel	GBK8/TK13	5 Speed with Synchro Cones Springs Keys Boot
LANDCRUISER	HZJ79	8/1999-	1HZ Diesel	GBK8/TK13	5 Speed with Synchro Cones Springs Keys Boot

